



NO.777-215

(Instruction Manual)

Please read this instruction manual carefully before you use it.

Contents



Tank x1




Controller x1

Instruction sheet x1


Antenna x1

Preparation


1. Loosen the buckle as per Pic.1 and take out the controller.




3. Unscrew the tank from the pedestal with a screwdriver (Pic.3)




5. Insert the antenna into the hole at the top of the controller, and tighten it.(Pic.5)




7. Turn the controller power switch to "ON" position, Press any key on the controller and the working indicator of the controller is "ON" it shows that has signal output this time.(pic.7)




2. Take out the plastic cover, unscrew the antenna.



4. Take out the fixed seat under the tank as shown below (Pic.4)





6. Use a screwdriver to loosen the screws on the battery cover by the counter-clockwise, insert 4 x "AA" batteries with the correct polarity, replace the battery cover and tighten the screws.(Pic.6) (Pic.6)



Charging


- (1). Set the switch of the mini tank on "OFF" position. Open the charging cover of the transmitter (as per pic.8 shown), plug it into the charging socket of the tank and start charging. Meanwhile the charging indicator will be "ON" (As per
- pic.9 shown)
 (2).When charge about 5
 minutes, the charging
 indicator will be "OFF"
 and charging is finished,
 The mini tank works about
 5 minutes when fully charged.





Operation

- Pull-up the antenna for better signal reception. Set the switch on the mini tank to "ON", the light on the tank is brightened, put the tank on the ground
- 2. The controller is full-function:
- The signal indicator lights up when any button on the controller is pressed. (Press remote control any key.)
- (2). Press forward/backward button, the tank will go forwards or backwards.
- (3).Pressing left/right button on the controller while the tank is running forward or backward, the tank will make left/right turns.



Cautions

- 1. Detachable small parts should be put away, do not let children devour.
- 2. If there is radio interference to operate the venue, please select the venue operator.
- 3. Remote control when low-power, please immediately stop the operation.
- 4. On backout after the removal, please do not place discarded to avoid contamination sanitation.
- 5. Would be grateful if your remote control model stored in dry, cool place.
- 6. Do not place near fire and high temperature, moist storage.
- 7. When the battery is water wet, add water to fully clean.
- 8. The use of remote control 4x1.5V "AA" batteries.
- 9. When the installation or replacement of the battery Please note polarity.
- 10. Rechargeable battery can only in the adult under quardianship charge.
- 11. Can not mix old and new or different types of battery.
- 12. Removed from the toy with the exhaustion of the battery.
- 13. Terminal should not short circuit.
- 14. Can not charge non-rechargeable batteries.
- 15. Remove the battery from the toy to have it to be recharged.
- 16. Please do not be a bad battery, battery pack into fire or decomposition in the water to avoid accidents.