













the app-controlled wireless spy tank (Instruction manual)



NO.777-270





iphone, ipad and Android Controller


The packaging must be retained since it contains important information







Instruction manual



Go App Store/Google play

Search"I-spy mini" download & install it -- Free!

Turn on the product


Go to setting and turn on wi-fi

Select the SSID address of your tank

Input the password "00000000"

Go to the control interface

Start game!



Enter to the control interface



Enter to the control interface




Enter to instruction manual

I-SPY MINI Name of the funtion key Camera Move motion mode Back out Power indicator Wi-fi mode Video camera Controller switch Viewer Interface rotate Camera Adjustment Throttle Left/right stick turn

Trimmer

- Function details
- 1. Camera:









Take photo

Video camera "OFF"

Video camera "ON"

3. Viewer:









View your files

Move motion mode "OFF"


Move motion mode "ON"

5. Camera Adjustment:






Manually move the camera lens up and down to capture angles of video.



6. Trimmer:




Press the trimmer right or left if the tank couldn't go forward straightly.



USB charge

- 1. Insert the USB Cable to the computer socket.
- 2. Turn "OFF" the power of the I-spy mini, connect the USB cable to the slot on the bottom of the I-spy mini. USB lights ON during charging & USB lights OFF when finish charging.
- 3. Charging time is about 2 hours. I-spy mini works more than 30 minutes.





Control methods

Control range: The control range of the i-spy mini is about 15 meters. Please avoid to overstep this control range, otherwise the i-spy mini will be out of control.

1. Forward


When push up the throttle stick, tank will moving forward.





2. Backward

When push down the throttle stick, tank will moving backward.



3. Forward and turn left

When push up the throttle stick and press left button, the tank will moves forward and turn left.





5. Backward and turn left

When push down the throttle stick and press left button, the tank will moves backward and turn left.





4. Forward and turn right

When push up the throttle stick and press right button, the tank will moves forward and turn right.





6. Backward and turn right

When push down the throttle stick and press right button, the tank will moves forward and turn right.







I-SPY MINI ----

Move motion mode

Switch to "move motion" mode, swing your hands like below instructions.

1. Left turn




















How to connect

- 1.Please check up the SSID number on the bottom of the tank. Slide the power switch on the tank to "on". The power will illuminate. Wait approximately 30 seconds and the singal light will start to blink slowly.
- 2.On your iPod touch, iPhone or iPad device, go to "Settings" and turn on the Wi-Fi. The SSID address of your tank will appears as an available connection.
- Note: Each i-spy mini has an unique SSID address (stick on the underside of the unit). If there are multiple tanks being used, the individual SSID addresses will appear at the same time. Select your tank's SSID address.
- 3.Select the tank to confirm the connection and input the passward "00000000". Ensure there is a check mark to the left of the SSID address and the Wi-Fi connection logo appears at the top of your device's screen.
- 4. Exit out of Setting and open the "i-spy mini".
- 5. The signal light will blink faster now.
- 6. When your device screen shows the view from the video camera, you are ready to start exploring.

Video

The tank can record the video of your driving route and save it as a file on memory

card, then you can replay it on your device screen:

 Press the "Video Camera" button and drive the tank on the route you want to record.

2. After you complete your route, press the "Video Camera" button again to save the record.

3. Press the "viewer" button to view the file. Select the file, it will be played on your device interface.



13

Camera

The tank can take snapshots . Press the "Camera" button to take a snapshot, the photo will be saved in the Photos Folder on memory card.

Cautions

- 1. When the battery is low in the i-spy mini, the control distance will be reduced.
- 2. The biggest control radius of the i-spy mini is 15 meters, please uses within this area, otherwise the i-spy mini will be out of control.
- 3. If the i-spy mini was damaged, distortion, please repaired in time.
- 4. Do not make the i-spy mini crashing, this may damage the i-spy mini.
- 5. Turn the tank off before cleaning. Wipe the tank with a soft, dry cloth. Ensure there is no hair or lint caught between the rear or front wheels and the drive shafts. Clean carefully with your fingers or a pair of tweezers.
- 6. Rechargeable batteries are only to be charged under adult supervision.
- 7. The supply terminals are not to be short-circuited.

Problem - Solving

Symptom	Cause	Correction
Wheel can't move.	ON/OFF switch is OFF.	• Set switch to "ON".
Suddenly stop.	Weak battery.	Recharge the tank.