

FUNCTIONAL EXPLANATION



37 keys

Professional and simulated keys are made of high quality material, with delicate touch.



LED teaching mode

The toy has a correction function: if a baby plays wrong, its lamp will light up to ensure kids can learn in the right way.



8 percussion effects

There are four drum buttons, and every button contains two kinds of drumming. When you press the "DRUM CHANGE" Button, the drum sound will transfer to other 4 kinds of percussion instrument. Total have 8 kinds of drum sound effect, include cymbal, high drum, snare drum, bass drum, (after press drum change) kettle drum, scraper, handbell, electronic drum.



8 styles of music

BLUES, SLOW ROCK, RUMBA, TANGO, SAMBA, COUNTRY, WALTZ, DISCO



8 instrument tones

There are Piano, guitar, organ, violin, trumpet, Mandolin, flute, music box these tones. They also can be converted to each other.



3 teaching modes

Our designer combining modern and scientific idea, building gradual reformation mode. If you have this toy, meaning that baby gets a great music teacher.

Guide1: press any key, it plays according to the music rhythm;

Guide 2: learn to play the demo music according to the keys with light on;

Guide 3: play a piece of music guided by light, and only accompaniment is left, practise playing according to the demo rhythm, if there is any error, there will be cue tone, and the demo key lights will shine in turns, then enter the next demo music.



Gorgeous light effect

When playing music or playing the piano, the 4 rhythm lights will flicker according to the rhythm of the music. Press "LED" to turn off the rhythm lights and key lights.

DEMOALL

22 demo songs

press "DEMO ALL" to play demo music in turns, and it is equipped with key lights to guide playing; after all music are played, it will stop, also can press single button to choose the next piece of music.

DEMO ONE

Single demo

press "DEMO ONE" to play one piece of music and press it again to play the next demo music; it will stop after one piece of music is finished; during the performing, there is key light to guide playing.

VOLUME+

Volume Adjustment

A total of 16 levels of volume can be adjusted and it can take care of the children's hearing.

VOLUME-

TEMPO+

Speed control key

16 scales for fine tuning of performing speed/ rhythm speed;


TEMPO-

REC

REC: press the record key, the indicator light is on, then play any key, it can be recorded; the upper limit of record is 40 notes.

REPLAY

REPLAY: press to play the recorded music/sound and this function is only valid after recording.



Switch



press it at any time to stop all operations and press it again to recover the current operation.



External MP3

The exquisite-designed mobile clip can help clip the mobile phone when it is pulled upward. The jack of the MP3 player can be connected with the mobile phone, IPAD, computer or MP3 Player.



Microphone

Tiny pink microphone can be adjusted into different angles to adapt to variety of baby's height.




lovely stool

The stool's rounded design makes it more comfortable and secure.

FUNCTION INTRODUCTION





- 37 keys
 - 8 percussion effects
 - 8 instrument tones
 - 8 styles of accompaniment
- 8 styles of music
 - 3 teaching modes
 - 22 pieces of demo music
 - Record/Play function
- External Mp3
 - Gorgeous light effect
 - Microphone
 - 2 minutes smart power saving

PART IN PICTURE



INSTALLATION DIAGRAM

The toy is intended to be assembled by adult.



Battery Installation Diagram:

This product uses 4X1.5V "AA" batteries. Open the battery cover, install 4X1.5V "AA" batteries into the battery box, then install the battery cover.

Note: pay attention to the correct installation of battery electrodes.

